

REAR-SUPPORTED THREAD TABLE ATTACHMENT

1. Remove the current ALL THREAD table from the machine.
(pull quick release pin underneath)
2. Remove the “U” bracket from the base of the machine.



3. Position the table with either the opening in the front or the back depending on how the operator will slide on garments.



4. Slide the table either towards the front or towards the back until it stops so the Black lower vertical face will engage with the Grey lower machine frame support as shown. Make sure the table is centered Left-to-Right.

Tighten the (2) HEX BOLTS to lock the table in place.

